

plery


User Manual

AX5400 Wireless Adapter

U168 Version 1.0


1 Device Installation

1-1 Insert the network adapter directly into the USB port on the computer.




2 Drive Installation

2-1 Enter my computer, find the "PteryWiFiDriver" drive disk, open the drive disk, double-click to install "pterywifidriver.exe".




2-2 After opening, select the corresponding language, confirm and click **Install** until the driver installation is complete.




2-3 After clicking finish, if you ask whether to restart the computer, if there is work in progress or a file being written, you can choose to restart later, if there is nothing else, it is recommended to choose to restart immediately.



2-4 Click on the network icon "  " in the bottom-right corner of the desktop, then click on the "  " icon.



2-5 Select the WiFi signal you want to connect, enter the password, and click "Next" to get connection.



3 Common Problems

- If the USB flash drive is not read:
 - (1) Please first check whether the computer USB can be used normally.
 - (2) For desktop computers, please try to use the USB interface behind the host (the rear interface of the host is more stable).
- If your computer can't connect to WiFi:
 - (1) If the WiFi icon is not detected after the driver is installed successfully (please try to restart the computer).
 - (2) If the WiFi cannot be retrieved or the WiFi connection fails (please check whether the router transmits WiFi normally and check whether the WiFi password is correct).



Warranty Card

Dear Valued Clients,

Thank you for purchasing our product. To ensure your after-sales service rights, please carefully read the following warranty regulations. The following situations are not covered under the free maintenance, and our company can provide paid services. Please note:

- Product malfunction or damage caused by improper installation, use, maintenance, or storage as per the user manual.
- Repairs requested beyond the warranty or replacement period; Unauthorized alteration or destruction of the product's barcode.
- Unauthorized modification of inherent configuration files or disassembly of the product without permission.
- Damage to the product caused by accidental factors or human actions, such as applying inappropriate voltage, exposure to high temperatures or water, mechanical damage, drops, severe oxidation, or rust, etc.
- Failures or damages caused by reasons other than the product's design, technology, manufacturing, or quality issues.

Maintenance Record

Date	Description of the malfunction	Maintenance records	Remarks

Note: Repairs must be conducted by authorized service units, with repair records filled out and stamped; otherwise, the repair records will be deemed invalid.

Copyright

STATEMENT

Shenzhen Ptery network Technology Co., LTD Copyright, all rights reserved

Without the specific written permission of the Company no entity or individual may copy, transcribe or translate part or all of the contents of this book without authorization. It may not be distributed or used for any commercial, profit-making purposes in any form or by any means (electronic, mechanical, photocopied, recorded or otherwise possible).

plery is a registered trademark of Shenzhen plery Network Technology Co., LTD. All other trademarks or registered trademarks mentioned in this document are the property of their respective owners.

The product specifications and information mentioned in this manual are for reference only and subject to change without prior notice. Unless otherwise agreed, this manual is for use only. All statements, information, etc. in this manual do not constitute a guarantee of any kind.

Shenzhen Ptery Network Tech Co., Ltd.

ADDRESS: 10th Floor, Building H, Huanan Digital Valley,
No. 1 Huanan Road, Longhua District, Shenzhen, China

EMAIL: plery810@gmail.com

WEBSITE: www.szplery.com